10 9 11 Heli Coils belong to frame in do not need to be replaced!

Loctite #243 on screws!
TORQUE 5Nm

TT Aero post
see assembly drawing S10-14

(optional:
TT Aero post with 50 mm offset
see S11-10)

13

14

6

2 1 3 Heli Coils belong to frame in do not need to be replaced!

Loctite #243 on screws!
TORQUE 5Nm

TORQUE 4.5Nm

8

12
Protection foil for
C/S 25x35x251mm

4 5

7

Loctite #243 on screws!

Use a short pcs of cable housing (indicated with two lines) for each shifter
cable in the BB area.
Use only top cap of double hole
satellite cable clip.

Loctite #243 on screws!
Note: Part 4 is assymetrical!
Make it flush on inside and outside.

	Canyon#	Part Name		Qty.
1	AI021827	FD hanger	E20-11	1PC
2		incl. screws		2PCS
3	AI016880	Heli Coil		2PCS
4	AI016881	stopper		2PCS
5	AI016882	adjustment nut		2PCS
6	AI022937	plastic clip-in cable holder	E56-12	1PC
7	AI011921	cable holder (for two cable)	E27-09	1SET
8	AI006942	water bottle screw		4PCS
9	AI011905	Seat Clamp	E25-09	1PC
10		incl. screws		2PCS
11	AI016879	Heli Coil		2PCS
12	AI037680	Protection foil		1PC
13	AI034600	TANGE IS-22		1SET
14	AI038525	aero fork F11-14		1PC

SPEEDMAX AL | R10-14

CANYON